

TOOLMASTER



Screw Seat to Suit Threading Tool Holders

Suits SER & SIR Tool Holders



TOOLMASTER Screw Seat to Suit Threading Tool Holders

Description

Screw Seat to Suit THREADING TOOL HOLDERS

Suits:

External Threading Tool Holders

Internal Threading Tool Holders

Specifications

ORDER CODE	L540
Part	SEAT SCREW
Suits	L031-L034, L038